

Panametrics portable liquid ultrasonic flowmeter at its best price for just **\$8,980 + GST**



GE's TransPort PT878 portable flow meter is a highly versatile, self-contained, portable transit-time system with options and accessories to meet all your liquid flow measurement needs. Its compact size; lightweight, rechargeable internal battery pack; and universal power supply charger make it the ideal on-the-go flowmeter.

Liquids can be accurately measured:

- Potable water
- Wastewater
- Cooling & heating water
- Ultrapure water
- Crude oil
- Refined hydrocarbons
- Diesel and fuel oils
- Lubricating oils
- Chemicals
- Beverages
- Other liquids



Panametrics Portable Liquid Ultrasonic Flowmeter accurately measures flow rate in perfectly clean liquids containing no "scatterers", where Doppler-type flowmeters cannot work. The TransPort flowmeter is suited for all standard transit-time applications, plus many that would prevent other transit-time flowmeters from working.

Limited stock, act quickly!

Your investment in this flowmeter is protected from the day-to-day rigors of industrial usage. The TransPort PT878 is equipped with a rubber boot that provides protection against vibration and shock. The completely sealed housing and ports meet IP67 requirements, so the unit will withstand submersion in up to 1 metre of water for limited periods of time. It will continue to function safely even if it is dropped in water.

Liquids can be accurately measured:

- Large, backlit LCD display
- Velocity, volumetric & energy flow rates
- Totalized flow and trend data
- Alphanumeric and graphic formats
- Logs over 100,000 flow data points, up to 32 site locations
- Suitable for most pipe sizes and materials, including lined pipe
- Optional energy measurement
- Optional thickness gauge

Click to view or go to YouTube search 'PT878 Portable ultrasonic flow meter overview'



Phone 1300 735 295

Email InfoIndustrialAU@thermofisher.com

ThermoFisher
SCIENTIFIC